



Exploded View and Replacement Parts List

PARTS LOCATION



REPLACEMENT PARTS LIST

Model No.EY37C4

Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
1	WEY37C4K3088	BASE UNIT	1	
2	WEY37C4L3127	USB RUBBER COVER	1	
3	WEY37C4K1448	CASE ASSEMBLY	1	
4	WEY37C4L3487	LENS	1	
5	WEY37C4L0217	RING RUBBER	1	
6	WEY37C4L3177	COVER BASE	1	
7	WEY37C4K0877	HINGE COVER	2	(φ25)
8	WEY37C4L1337	HINGE ASSEMBLY	1	
9	WEY37C4L0877	HINGE COVER	2	(φ13)
10	WEY37C4L1357	HINGE ASSEMBLY FOR HANDLE	1	
11	WEY37C4L3217	HANDLE UNIT	1	
12	WEY37C4L2107	MAIN MODULE	1	
13	WEY37C4L2207	BT MODULE	1	
14	WEY37C4L2307	LED MODULE	1	
15	WEY37C4L2407	4-PIN CONNECTOR	1	
16	WEY37C4B6017	TAPPING SCREW	4	(2.6*8),(5PCS/PK)
17	WEY37C4B6027	TAPPING SCREW	4	(2.6*6),(5PCS/PK)
18	WEY37C4B6037	SELF TAPPING SCREW	8	(2.6*6),(5PCS/PK)
19	WEY37C4B6047	TAPPING SCREW	12	(2.6*10),(5PCS/PK)
20	WEY37C4B7107	RUBBER FOOT	4	(1sheet/PK)
-	WEY37C4K8108	OPERATING INSTRUCTIONS	1	
-	WEY003W8957	GREASE (PERMALUB)	1	
-	WEYFLA4AK777	HEAT RESISTANT TAPE	1	(30m/ROLL)