


9 Exploded View and Replacement Parts List

9.1. Exploded View for EYFMA1B



9.2. Replacement Parts List for EYFMA1B

Safety	Ref. No.	Part No.	Part Name & Description	Quantity	Remarks
	1	WEYFMA1BK308	HOUSING AB SET	1	
	2	WEYFMA1JL968	TIGHT SCREW W/WASHER	4	(M4*25)
	3	WEYFMA1JS317	FIXATION COVER	1	
	4	WEY6631K0867	SLIDER	1	
	5	WEYFMA1BL119	ANVIL	1	
	6	WEYFMA1JL107	DRIVING SHAFT ASSEMBLY	1	
	7	WEY6504L1357	PLANET GEAR	2	(2PCS/PK)
	8	WEY6506L1346	PIN	2	(2PCS/PK)
	9	WEYFLA1AL007	MOTOR MOUNTING PLATE ASSEMBLY	1	
	10	WEYFLA1AL497	BEARING	1	
	11	WEYT611L0967	O-RING	1	(43.6*1.3)
	12	WEYFLA1AL147	MOTOR ROTOR ASSEMBLY	1	
	13	WEYFMA1JL028	STATOR	1	
	14	WEYFLA1AK207	SWITCH ASSEMBLY	1	
	15	WEY7540L2157	BATTERY TERMINAL BLOCK	1	
	16	WEYFLA1AL207	RIBBON CABLE	1	
	17	WEYFMA1JL218	MODULE ASSEMBLY	1	
	18	WEYFLA1AL297	HARNESS	1	
	19	WEYFLA3JL227	LED ASSEMBLY	1	
	20	WEYFLA1AK337	OPERATION PANEL	1	
	21	WEYFLA1AK327	F/R SELECTOR HANDLE	1	
	22	WEYFLA1AL377	TIGHTENING CONFIRMATION LAMP COVER	1	
	23	WEYFMA1JL337	DISCERNMENT PLATE	1	
	24	WEY6930K9037	TIGHT SCREW	9	(K3*20)
	-	WEYFLA4AR819	OPERATING INSTRUCTIONS	1	
	-	WEY002X8977	DOUBREX GREASE	1	
	-	WEWGW2	FLOIL GREASE	1	