


OHTAKE OM26M Serie


OM26M35 OM26M40 OM26M50 OM26M60



No.	Part Number	Name of Part
B	-	Block "B" Assy
1	ZZM00363	Binding Head Tapping Screw M2.6*8 Ni (10pcs)
2	TPO11048#01	Front Bottom Cover Assy (With Sticker)
3	TPO00906	Front Cover Assy
4	ZZM00159	Plus Truss Head Screw M2.6*3 Ni (10pcs)
5	TPO00905	Bit Guide Assy: OM-26M
6	ZZM00261	Hex. Socket Head Bolt PW,SW M2.6*5 (10pcs)
7	TPO00913	Bit Guide Unit
8	TPO00914	Bit Guide Attaching Unit
9	TPO01002#03	Front Sensor Detector LED (With Harness)
10	RTF-5010	LED Bezel
11	TPO01003#04	LED Junction Cable
12	ZZM00160	Plus Truss Head Screw M2.6*4 Ni (10pcs)
13	TPO11049#01	Outside Cover Assy
14	TPO01002#05	Power Switch (With Harness)
15	TPO01002#06	Power Plug (With Harness)
16	TPO00711	Upper Lid

OHTAKE OM26M Serie


OM26M35 OM26M40 OM26M50 OM26M60



No.	Part Number	Name of Part
C	-	Block "C" Assy
D	TPO11031	Motor Bracket Unit
	TPO40620#01	Escaper Unit:OM2-26M M2.0
	TPO40620#02	Escaper Unit:OM2-26M M2.3
	TPO40620#03	Escaper Unit:OM2-26M M2.6
	TPO40620#04	Escaper Unit:OM2-26M M3.0
	TPO40620#05	Escaper Unit:OM2-26M M3.5
	TPO40620#06	Escaper Unit:OM2-26M M4.0
	TPO40620#07	Escaper Unit:OM2-26M M5.0
	TPO40620#08	Escaper Unit:OM2-26M M6.0
E	※2 TPO00620#01	Escaper Unit:OM-26M M2.0
	※2 TPO00620#02	Escaper Unit:OM-26M M2.3
	※2 TPO00620#03	Escaper Unit:OM-26M M2.6
	※2 TPO00620#04	Escaper Unit:OM-26M M3.0
	※2 TPO00620#05	Escaper Unit:OM-26M M3.5
	※2 TPO00620#06	Escaper Unit:OM-26M M4.0
	※2 TPO00620#07	Escaper Unit:OM-26M M5.0
	※2 TPO00620#08	Escaper Unit:OM-26M M6.0
1	TEK81011	Drive Belt(φ5-285)
2	ZZM00029	Pan Head Screw PW,SW M2.6*6 (10pcs)
3	TPO00808	Extension Spring
4	NSB02058	Brush Driving Gear Large 3
5	ZZM00510	E-Type Snap Ring E-3 (10pcs)
6	TPO00409	Stainless Spacer
7	ZZM00055	Pan Head Screw PW,SW M2.6*8 Loosening Prevention (10pcs)
8	ZZM00620	Pan Head Screw PW,SW M3*7 Loosening Prevention (10pcs)
9	TPO11033	Solenoid Unit
10	TPO01003#15	Solenoid Junction Cable
11	TPO11034	Escaper Fixing Unit
12	CS-9	Coated Clip(10pcs)
	※3 OMM20SET	Rail set M2.0
	※3 OMM23SET	Rail set M2.3
	※3 OMM26SET	Rail set M2.6
	※3 OMM30SET	Rail set M3.0
	※3 OMM35SET	Rail set M3.5
	※3 OMM40SET	Rail set M4.0
	※3 OMM50SET	Rail set M5.0
	※3 OMM60SET	Rail set M6.0
13		
14	TPO11035	Presser Plate Unit
15	ZZM00100	Plus Countersunk Head Screw M2.6*5 (10pcs)
16	TPO00809	Compression Spring
17	TPO00708	Presser Plate #2
18	ZZM00261	Hex. Socket Head Bolt PW,SW M2.6*5 (10pcs)
19	TPO01003#14	Sensor Junction Cable-Front Sensor
20	TPO01003#02	Sensor Junction Cable-Origin Sensor
21	TPO01003#08	Motor Junction Cable
22	TPO00908	Brush Assy
23	TPO90988	Brush Bracket
24	TPO90990	Brush
25	TPO90989	Brush Holding Plate
26	ZZM01008	Hex. Socket Head Bolt PW,SW M2.6*10 (10pcs)
	TPO11011#01	Passing Plate:OM20-30 M2.0-3.0
	TPO11011#02	Passing Plate:OM35-40 M3.5-4.0
	TPO11011#03	Passing Plate:OM50 M5.0
	TPO11011#04	Passing Plate:OM60 M6.0
27		
28	ZPV00001#18	SPM Board For OM
29	CS-1	Coated Clip(10pcs)
30	ZPV00001#05	Main Circuit Board For OM
31	TPO01003#07	Signal Junction Cable
32	TPO01003#10	Power Junction Cable
33	TPO01003#11	Jumper Connector
34	TPO01002#18	Signal Harness
35	TPO00701	Pully Cover
36	ZZM00028	Pan Head Screw PW,SW M2.6*5 (10pcs)

OHTAKE OM26M Serie


OM26M35 OM26M40 OM26M50 OM26M60



No.	Part Number	Name of Part
1	TPO11032	Magnet Arm Unit
2	ZZM00397	Plain Washer M6 (10pcs)
3	ZZM00536	C-Type Snap Ring Nominal 6 (10pcs)
4	TPO00407	Magnetic Arm Spring
5	TPO00508	Roller Arm: Press-fit
6	TPO00461	Separating Rail
7	ZZM00102	Plus Countersunk Head Screw M2.6*8 (10pcs)
8	TPO11039	Brush Shaft Assy
9	ZZM00512	E-Type Snap Ring E-5 (10pcs)
10	TPO11310	Scraper Left (t1.0)
11	TPO91202	Scraper Right
12	ZZM00157	Plus Truss Head Screw M2*3 Ni (10pcs)
13	TM-K5W	Rubber Foot
14	TPO00701	Right Wall 5
15	ZZM00120	Plus Countersunk Head Screw M2*4, Ni Plating, Looseness Prevention (10pcs)
16	TPO00904	Fixing Bolt

OHTAKE OM26M Serie


OM26M35 OM26M40 OM26M50 OM26M60



No.	Part Number	Name of Part
1	TPO11040	Motor Bracket (With Shaft)
2	TPO01002#17	Main Motor (With Harness)
3	ZZM00620	Pan Head Screw PW,SW M3*7 Loosening Prevention (10pcs)
4	TPO00509	Driving Pulley
5	ZZM00388	Hex. Socket Head Screw M4*8 Loosening Prevention (10pcs)
6	TPO90982	Roller: Brush Driving Shaft

OHTAKE OM26M Serie


OM26M35 OM26M40 OM26M50 OM26M60



No.	Part Number	Name of Part
F	TPO20806#05	Stopper Assy M2.0:SIES20
	TPO20806#06	Stopper Assy M2.3:SIES23
	TPO20806#07	Stopper Assy M2.6:SIES26
	TPO20806#08	Stopper Assy M3.0:SIES30
	TPO20806#09	Stopper Assy M3.5:SIES35
	TPO20806#10	Stopper Assy M4.0:SIES40
	TPO20806#11	Stopper Assy M5.0:SIES50
	TPO20806#12	Stopper Assy M6.0:SIES60
1	TPO40622	Escaper Driving Unit:OM2-26M
	※2 TPO00618	Escaper Driving Unit(M)
2	TPO00608#05	Escaper Guide Right M2.0:SIEM20
	TPO00608#06	Escaper Guide Right M2.3:SIEM23
	TPO00608#07	Escaper Guide Right M2.6:SIEM26
	TPO00608#08	Escaper Guide Right M3.0:SIEM30
	TPO00608#09	Escaper Guide Right M3.5:SIEM35
	TPO00608#10	Escaper Guide Right M4.0:SIEM40
	TPO00608#11	Escaper Guide Right M5.0:SIEM50
	TPO00608#12	Escaper Guide Right M6.0:SIEM60
3	ZZM00060	Pan Head Screw PW(s),SW M2.6*5 (10pcs)
4	ZZM00614	Plus Countersunk Head Screw M2.6*5,Nylok (10pcs)
5	TPO00622	Front Sensor Unit
6	ZZM00261	Hex. Socket Head Bolt PW,SW M2.6*5 (10pcs)
7	TPO00604#05	Escaper:M2.0 SIE20
	TPO00604#06	Escaper:M2.3 SIE23
	TPO00604#07	Escaper:M2.6 SIE26
	TPO00604#08	Escaper:M3.0 SIE30
	TPO00604#09	Escaper:M3.5 SIE35
	TPO00604#10	Escaper:M4.0 SIE40
	TPO00604#11	Escaper:M5.0 SIE50
	TPO00604#12	Escaper:M6.0 SIE60
8	ZZM00071	Pan Head Screw PW(s),SW M2*8 Ni (10pcs)
9	TPO01002#13	Front Sensor (With Harness)
10	NSR08621	Light Receiver Slit Plate
11	NSB02125	Adjusting Screw

OHTAKE OM26M Serie

OM26M35 OM26M40 OM26M50 OM26M60



No.	Part Number	Name of Part
1	TPO20812#05	Escaper Guide Left(With Flange):M2.0
	TPO20812#06	Escaper Guide Left(With Flange):M2.3
	TPO20812#07	Escaper Guide Left(With Flange):M2.6
	TPO20812#08	Escaper Guide Left(With Flange):M3.0
	TPO20812#09	Escaper Guide Left(With Flange):M3.5
	TPO20812#10	Escaper Guide Left(With Flange):M4.0
	TPO20812#11	Escaper Guide Left(With Flange):M5.0
	TPO20812#12	Escaper Guide Left(With Flange):M6.0
2	ZZM00394	Plain Washer M3 (10pcs)
3	TPO20804	E-Stopper Spring Stopping Screw Assy
4	TPO20803	E-Stopper Spring Holding Assy
5	TPO91101	E-Stopper Spring
6	TPO00512	E-Stopper