delvo®

ELECTRIC SCREW-DRIVER

DLV8530-PKE/MKE DLV8630-PKE/MKE
DLV8540-PKE/MKE DLV8640-PKE/MKE
DLV8550-PKE/MKE DLV8650-PKE/MKE

No.	PARTS NAME	PARTS No.
1	Spring Ajusting Ring	5461085K
2	Stop Ring	5462316K
3	Holder Collar	5461051K
4	Holder Spring	5461050K
5	Holder Clamp	5461049K
6	Stop Ring ····· (2)	5462712K
7	Roller Pin [φ2×17.8mm] ····· (3)	5462735K
8	Nose Nut Assembly	5461088A
9	Scale Label	5461089K
10	Plate For Spring	5461030K
11	Clutch Spring	
	for DLV8530	5462136K
	for DLV8630	5461042K
	for DLV8540/8640	5464062K
	for DLV8550/8650	5464008K
12	Taper-Ring Assembly	
	for DLV8530/8540/8550/8640	5461019A
	for DLV8630	5461020A
	for DLV8650	5461019B
13	Steel Ball [3/32″dia] ····· (2)	5462783K
14	Steel Ball [5/32″dia] ····· (4)	5462704K
15	Bit Holder Assembly	5461027A
16	Pilot (A)	5461077K
17	Steel Ball [1/16″dia]	5462705K
18	Washer for Push Spring	5461028K
19	Push Spring	5461029K
20	Cam Guide	
	for DLV8630	5461023K
	for all others	5461022K
21	Steel Ball [2mmdia] ····· (27)	5462703K
22	Cam	5461086K
23	Roller Pin [φ4.5×4.5mm] ····· (2)	5464701K
24	Washer	
	for DLV8630	5461025K
	for all others	5461087K
25	Ball Bearing	5461035K
26	Gear Base (B) Assembly	
	for DLV8530/8540/8550 ····· (2)	5461036A
	for DLV8640 ····· (2)	5461036B
	for DLV8660 ····· (2)	5461036C
	for DLV8630 ····· (1)	5461036D
27	Gear Base Assenbly	5461036E
28	Idle Gear	
	for DLV8530 ····· (6)	5462116K
	for DLV8540 ····· (6)	5462202K
	for DLV8550 ····· (6)	5461093K
	for DLV8630 ····· (3)	
	for DLV8640 ····· (6)	5464508K
	for DLV8650 ····· (6)	5464513K
29	Spindle Gear	
	for DLV8530/8630	5461044K
	for DLV8540	5461045K
	for DLV8550	5461277K
	for DLV8640	5461046K
	for DLV8650	5461048K
30	Gear Case	
	for DLV8530	5461090K
	for DLV8540	5461092K
	for DLV8550/8630/8640/8660	5461091K
31	Gear Cover	5461302K
32	Pilot Rod (I)	5461336K
33	Motor Gear	
	for DLV8530	5461013K
	for DLV8540	5461014K
	for DLV8550/8630	5461275K
	for DLV8640	5461016K
	for DLV8650	5461017K

No.	PARTS NAME	PARTS No.
34	Pilot Rod (G)	5461276K
35	Fan	
	for DLV8630	5461152K
	for all others	5462111K
36	Pilot Rod (J)	5461012K
37	End Cover (G)	5461096K
38	Assembly Spring	5461099K
39	Yoke Assembly	
	for DLV8530/8540/8550	5462002K
	for DLV8630/8640/8660	5462008K
40	Ball Bearing	5461094K
41	Rotor Assembly	
	for DLV8530/8540/8550	5462048K
	for DLV8630	5462049K
	for DLV8640/8650	5462050K
42	Ball Bearing	5462101K
43	End Cover (R)	5461323K
44	Brush Assembly ····· (2)	5461377K
45	Brush Cap ····· (2)	5462106K
46	Pilot Rod (D)	5462168K
47	Nut	5462709K
48	Ajusting Screw	5462169K
49	Spring for Pilot	5462171K
	Circuit Board Assembly for MicroSwitch	5461375K
51	Circuit Board for MicroSwitch	5461328K
52	Microswitch (Start)	5461119K
53	Plate	5462167K
54	Microswitch (Brake)	5461120K
55	Screw [M2.3x12mm] ····· (4)	5462708K
56	Screw [M2.3x5mm] ····· (2)	5462729K
	Circuit Board Assembly for Change-Over Switch	5461374K
58	Circuit Board for Change-Over Switch	5461324K
59	Change-Over Switch	5461069K
60	Change-Over Switch Rocker	
	for DLV8530 (Orange)	5462192K
	for DLV8540 (White)	5462193K
	for DLV8550 (Blue)	5462196K
	for DLV8630 (Red)	5462195K
	for DLV8640 (Gray)	5462191K
	for DLV8650 (Yellow)	5462194K
61	LED for Torque-Reach	
62	Receptacle Assembly	5461332K
63	Frame (A)	5461320K
	Frame (B)	
64	Screw ····· (3)	5462710K
65	Coupling	5461322K
66	Rating Label	
67	Warning Label	
68	Power Cord Assembly	5461330K
69	Lifting Hook Assembly	5462181K
26	Gear Base Assembly	
	for DLV8550 ····· (1)	5461036A
70	Gear Base Assembly	
	for DLV8550 ····· (1)	5461278A
71	Receptacle Assembly for MKE Type	5461381K
72	Screw[XK2.6×4]	5461333K
73	Vibration Proof Seal	5461328K

Original drawing OWDL2277c

THIRD ANGLE DRAWING	NIPPON ELECTRIC INDUSTRY Co.,LTD. TOKYO JAPAN		
DIMENSION IN (mm)			
SCALE	DRAWING TITLE	PARTS LIST	
DATE NOV. 18. 1996			
ORDER NO.	FOR		
APPROVED / CHECKED	DESINED / DRAWN	DWG. NO.	OW20589c
M. Ujiie	T. Okamoto		

c) REVISION JAN. 14. 2000

a) REVISION DEC. 19. 1996